

ASPHALT COLD PATCH

PRODUCT No. 1701-58

PRODUCT DESCRIPTION

QUIKRETE® Asphalt Cold Patch is an environmentally friendly product specially formulated with a high percentage (>90%) of graded recycled asphalt pavement and special binding agent.

PRODUCT USE

QUIKRETE® Asphalt Cold Patch is designed to be used for repairing potholes and cracks over 1" (25.4 mm) wide in asphalt pavements and has the following features:

- No heating or mixing required
- Repair area is ready for immediate use
- Permanently bonds to surrounding asphalt pavement
- Very low Volatile Organic Compound (VOC) emissions
- Meets air quality standards of AQMD rule 1108.

SIZES

- QUIKRETE® Asphalt Cold - 50 lb (22.7 kg) bags

YIELD

- Each 50 lb (22.7 kg) bag will yield approximately 0.32 ft³ (0.009 m³) when properly compacted and will cover an area of approximately 3.8 ft² (0.36 m²) when placed at a thickness of 1" (25.4 mm).

INSTALLATION

SURFACE PREPARATION

Square cut the vertical sides of the hole to provide for proper confinement of the patch. Remove all loose material. Sweep the area thoroughly. It is recommended to remove standing water.

APPLICATION

Follow these procedures when applying QUIKRETE® Asphalt Cold Patch:

- Fill the hole with QUIKRETE® Asphalt Cold Patch to a height of 1/2" (12.7 mm) above the surrounding area. Do not apply less than 1" (25.4 mm) thick. Material over 1" (25.4 mm) must be applied in 1" (25.4 mm) lifts which must be adequately compacted before additional material is added.
- Compact to a level surface with a tamper. (Patch may be covered with a piece of plywood and driven over with the front wheel of a car to further pack material.)

DIVISION 32

Flexible Pavement Repair
32 01 17



- Traffic can begin immediately after satisfactorily leveling and compacting

PRECAUTIONS

- Apply QUIKRETE® Asphalt Cold Patch at a depth of 1" - 3" (25.4 - 76 mm). Apply in 1" (25.4 mm) lifts so that adequate compaction of each layer can be accomplished before more material is added. The product is not designed for curbs or other unconfined areas. Restrict the size of the repair to an area of approximately 3' x 3' (0.9 x 0.9 m).
- Avoid getting Asphalt Cold Patch on hands or clothing
- Avoid dry turning tires on patched area for at least 24 hours (longer in cold weather)
- Allow patch to cure at least 30 days if applying a driveway sealer

WARRANTY

The QUIKRETE® Companies warrant this product to be of merchantable quality when used or applied in accordance with the instructions herein. The product is not warranted as suitable for any purpose or use other than the general purpose for which it is intended. Liability under this warranty is limited to the replacement of its product (as purchased) found to be defective, or at the shipping companies' option, to refund the purchase price. In the event of a claim under this warranty, notice must be given to The QUIKRETE® Companies in writing. This limited warranty is issued and accepted in lieu of all other express warranties and expressly excludes liability for consequential damages.

The QUIKRETE® Companies
One Securities Centre
3490 Piedmont Rd., NE, Suite 1300, Atlanta, GA 30305
(404) 634-9100 • Fax: (404) 842-1425

* Refer to www.quikrete.com for the most current technical data, MSDS, and guide specifications